

# CHECKING THE THERMOSTAT


MODELS: 80VP, 125VP, 170VP



## WARNING

LP & NG ARE EXTREMELY FLAMMABLE SO  
TAKE EXTRA PRECAUTIONS WHEN  
PERFORMING ANY WORK TO THE HEATER

PART # 40931 OR #20849 AQUASTAR VP MODELS



The thermostat is bad if the piston rests below the lip **OR** if the "end feel" is spongy when the end of the piston is pushed **DOWN HARD**.